 Discovery Labs	STANDARD OPERATING PROCEDURE			
	SOP No.:	SOP-ED-024-00	Effective Date:	
	Supersedes :	Nil	Next Review Date:	
	Department:	Engineering	Page:	1 of 3
TITLE: OPERATING & PREVENTIVE MAINTENANCE PROCEDURE FOR NITROGEN GAS PLANT				

1.0 PURPOSE:

To describe a procedure for operation and Preventive Maintenance of Nitrogen gas plant.

2.0 SCOPE:

This procedure is applicable to operation and preventive maintenance of Nitrogen Gas plant at Discovery Laboratories Pvt Ltd.

3.0 RESPONSIBILITY:

3.1 Technician and Electrician

Is the responsible to operate follow the safety precautions during the preventive maintenance works

3.2 Engineer:

It is the responsible to monitor the activity.


4.0 DEFINITIONS: NIL

5.0 PROCEDURE :

5.1 Start-up Procedure

- 5.1.1 Check that all electrical connections are O.K. Power and control panel is getting power supply.
- 5.1.2 Check the Zeroing of all instruments.
- 5.1.3 Ensure that manual drain valves of all equipment are closed.
- 5.1.4 Switch 'ON' the main switch & control supply switch and accept 'hooter'.
- 5.1.5 Start the air compressor. (push Button on Air Comp. Control Panel)
- 5.1.6 As soon as air receiver pressure reaches 5.5 Kg/Cm²g, the sequence of PSA starts automatically.
- 5.1.7 Observe the operation of the Units for same time and see that the PSA module is working all right. Check that the pressurization and depressurization of towers are O.K.
- 5.1.8 Check the maximum pressure in the adsorbing towers of PSA unit goes to 7.0 Kg/Cm²g. If required control that airflow by the globe valve V9 provided just at the air inlet

	Prepared by	Reviewed by	Approved by
Sign & Date			
Name	T. Kiran Prasad	M. Ramesh	N. Sreedhar
Department	Engineering	Engineering	Quality

 Discovery Labs	STANDARD OPERATING PROCEDURE			
	SOP No.:	SOP-ED-024-00	Effective Date:	
	Supersedes :	Nil	Next Review Date:	
	Department:	Engineering	Page:	2 of 3
TITLE: OPERATING & PREVENTIVE MAINTENANCE PROCEDURE FOR NITROGEN GAS PLANT				

into the PSA module. Settings should be disturbed only after watching the result for 15-20 minutes.

- 5.1.9 Check and control the Globe valve V10, to produce the desired Nitrogen Flow rate.
- 5.1.10 After the pressure in surge tank has reached up to 6.0 Kg/Cm²g, open and set the globe valve in Nitrogen line Rota meter for desired nitrogen flow. (Maximum 15 Nm³/Hr).
- 5.1.11 Check that the purity of raw nitrogen is at-least 99.9% i.e. percentage oxygen analyzer indicates a reading of 0.1%.
- 5.1.12 Close vent valve by selecting ON Position in SW-3.
- 5.1.13 Record the operation conditions after regular intervals of 1 hour.


5.2 Normal Shutdown:

- 5.2.1 Open Vent valve by selecting OFF position in SW-3.
- 5.2.2 De-pressurize system by opening various drain valves. However, if the plant is to be re-started within 2-3 hours, it is not required.

5.3 Preventive Maintenance of Nitrogen Plant

- 5.3.1 Start the Air Compressor and observe for any abnormal sound and vibration
- 5.3.2 Check the air leakages throughout the system
- 5.3.3 Check the pneumatic valves for opening and closing
- 5.3.4 Check the N₂ storage tank for any air leakages
- 5.3.5 Check the safety valves working condition
- 5.3.6 Isolate the power supply by removing the fuses of the system
- 5.3.7 Clean the air filter
- 5.3.8 Check the air compressor oil level
- 5.3.9 Check the compressor for any oil leakage
- 5.3.10 Check the belt condition for wear and tear
- 5.3.11 Tighten all exterior bolts & Nuts
- 5.3.12 Check for any loose connection in motor terminal

	Prepared by	Reviewed by	Approved by
Sign & Date			
Name	T. Kiran Prasad	M. Ramesh	N. Sreedhar
Department	Engineering	Engineering	Quality

 Discovery Labs	STANDARD OPERATING PROCEDURE			
	SOP No.:	SOP-ED-024-00	Effective Date:	
	Supersedes :	Nil	Next Review Date:	
	Department:	Engineering	Page:	3 of 3
TITLE: OPERATING & PREVENTIVE MAINTENANCE PROCEDURE FOR NITROGEN GAS PLANT				

5.3.13 Check the earth connection of motor & System

5.3.14 Check the bearings & pulley for abnormal sound

5.3.15 Record the preventive maintenance observation and action in Preventive maintenance checklist for Nitrogen Plant, ED024-FM068

5.3.16 Record the preventive maintenance activity in Equipment History record, ED010-FM011

1.0 FORMATS / ANNEXURE(S):

Nitrogen gas Plant Log Book : ED024-FM067

Preventive maintenance checklist for Nitrogen gas Plant : ED024-FM068

2.0 CHANGE HISTORY:

Revision No.	Effective Date	Details of Revision	Ref. CCF No.
00	04.04.2018	New SOP Prepared	CCF-GEN-18011

	Prepared by	Reviewed by	Approved by
Sign & Date			
Name	T. Kiran Prasad	M. Ramesh	N. Sreedhar
Department	Engineering	Engineering	Quality